



How to Fix A Warped Frisbee Disc

This guide will help you repair a warped frisbee disc back to its original shape.

Written By: Bryce Petersen



INTRODUCTION

For frisbee owners, a warped disc is a common problem due to prolonged sun exposure or moderate wear over time. For most discs, this warping can often be undone with some gentle manipulation. This fix involves a simple set up, and then letting the frisbee sit for approximately 1 hour.



TOOLS:


- [Towel](#) (1)
 - [Microwave safe bowl](#) (1)
 - [Textbook \(or large book\)](#) (1)
-

Step 1 — How to Fix A Warped Frisbee Disc




- Place the frisbee disc on a flat surface with the concave side facing up. Lay a towel down flat over the frisbee.

Step 2



- Take the bowl and fill halfway full with water. Microwave until water is boiling.

 The bowl will be hot, so handle it with care.

Step 3




- Take the bowl with boiling water and place it on top of the frisbee and the towel.

Step 4



- Add a textbook as a weight to sit on top of the bowl.
- Let everything sit for 1 hour

Step 5



- Remove any weights, the bowl, and the towel. Check to see if the disc is still warped.
- ⓘ If it is still warped repeat this process one more time.

The time taken to fix the warping on your frisbee may vary based on how thick the plastic is.

This document was last generated on 2017-06-17 04:29:16 PM.